

TECHNICAL INFORMATION

ORWO HF55/HF65 Processing Instruction

ORWO holographic film HF 55

ORWO holographic film HF 65

Processing:	Developer SM6	approx. 2 min
Rinse:	Water	1 – 2 min.
Bleaching:	PBU-Amidol	bleaching to clearness, approx. 3 min
End rinse:	Water	5 min
Drying:	Material can be dried with warm treatment (warm air).	

Formula of SM6:

Sodium hydroxide	12.0 g
Methyl phenidone	6.0 g
Ascorbic acid	18.0 g
Sodium phosphate (dibasic)	28.4 g
(if 12 H ₂ O)	71.6 g
Water	for 1.0 l

Formula of PBU-Amidol:

Potassium persulphate	10.0 g
Citric acid	50.0 g
Cupric bromide	1.0 g
Potassium bromide	20.0 g
Amidol	1.0 g
Water	for 1.0 l



FILMOTEC GmbH
Ortsteil Wolfen
ChemiePark Bitterfeld Wolfen
Areal A, Röntgenstraße Geb. 415
06766 Bitterfeld-Wolfen
Tel.: +49 (0) - 3494 - 36 96 80
Fax: +49 (0) - 3494 - 36 96 82
filmotec@filmotec.de
www.filmotec.de